

AQUAFIT MASKING PROCESS



➤ BLOW OFF & PRE-CLEAN

1. Blow off the vehicle and remove all dust inclusion by the use of an airline and gun nozzle.



➤ PRE-TAPE

2. When necessary use foam edge and pre-tape all surrounding panels adjacent to the repaired area.



➤ SHEET UP

3. Dispense the AQUAFIT over the vehicle directly from the roll before cutting to length.



➤ CUT OUT

4. Using a safety blade, cut the AQUAFIT along the edge of the panel to be repaired.



➤ TAPE DOWN

5. Straighten out any creases in the AQUAFIT and tape down.



➤ LOCAL MASK FOR PRIMER

6. Add masking for localised primer.



➤ SAND & REPAIR MASKING

7. After sanding, repair the masking cover where necessary.



➤ INSPECT HARD MASKING EDGES

8. Remove sanding debris from all apertures and repair if necessary the soft & hard edge masking.



➤ BLOW OFF

9. Blow off the vehicle and remove all surface dust.



➤ DE-GREASE PRIOR TO PAINT

10. De-grease the outer panel & masking prior to paint.



➤ TACK & PAINT

11. The static properties of the AQUAFIT help reduce dirt inclusions in the paint finish.



12. The anti-staining AQUAFIT reduces the risk of paint & ghost masks and the additional time spent polishing.